



Reusable Face Mask



DGA tested



Reusable



95% Filtration



OEKO-TEX® 100 Evolon® by Freudenberg



Light weight 0.17 oz



Machine washing



Steam ironing



AFNOR SPEC S76-001 NBN/DTD S65-001 UNE 0065



- Perfect fit, adjustable nose-wire & elastic strap
- Double layer, high quality breathable certified textile
- Ultra high protection, no filter required
- Light & comfortable, 0.17 oz weight
- Reusable & washable – minimum 50x
- Latex-free, hypo-allergy friendly & chemical-free
- Handmade in North-America by contTeyor

Technical specifications contTeyor Face Mask

- One-size-fits-all adult; children size available
- Wrap around face shield by 3 stitched folds
- Complies with AFNOR SPEC S76-001 & NBN/DTD S65-001 & UNE 0065
- OEKO-TEX® 100 Class 1 certified textile, Evo 40 PK, Evolon® by Freudenberg
- Non-woven, microfilaments polyester/polyamide
- Latex-free, hypo-allergy friendly & free of chemicals
- High breathability: breathing resistance <math><5.0 \text{ mm H}_2\text{O}/\text{cm}^2</math>
- 95,1% protection against aerosols of 3µm particle size
- Dimensions: 8 inches (ear to ear) x 8.4 inches (nose to chin)

Why contTeyor?

Our core business is sustainable packaging, so no waste!

We decided to convert a part of our textile production for the manufacturing of masks and visors. We are proud to be part of the global battle against COVID-19 and to support our communities.



Important user information

1. Recommended for non-medical, personal use
2. For hygienic purposes: change mask every day

How to use and put on the mask correctly

1. Wash and disinfect your hands thoroughly before using the mask
2. Cover mouth and nose with the mask and position elastic ear straps behind the ears
3. The mask has a nose clip, place it on your face in the nasal area and tighten to fit the shape of your face
4. Make sure that there are no gaps between the face and mask
5. To remove the mask, grab it by the elastic straps without touching front of the mask
6. After removing the mask, wash and disinfect your hands
7. Avoid touching the mask while using it, if you do, wash or disinfect your hands thoroughly

Care instructions

1. Machine wash at 140° F with a conventional detergent; preferably put the mask in a separate laundry bag
2. Air or mechanical drying, always followed by steam ironing at a temperature of 265° F

After the first washes, it is possible to see “pilling” appear on the fabric; this has no effect on the filtration quality of the mask



Product information conTeyor Face Mask NAFTA – Eng – v3

Disease prevention



DISCLAIMER: This product was designed as a community mask and is not designed to be used by healthcare professionals. The use of this product is for non-medical purposes only and strictly at the individual's own risk. This product is not suitable for children under 3 years. The level of effectiveness depends on its use and circumstances. Considering the urgent need on short notice globally, the development process did not allow for extensive field testing and certification. The manufacturer assumes no liability for the use or misuse of this product.

conTeyor Packaging Solutions, S.A. de C.V., Av. Valle de San Isidro #530, Bosques de San Isidro, 45133 Zapopan, Jalisco, México
conTeyor US Inc., 1801 Michael St., Madison Heights, MI 48071, United States
conteyor.com